

# Overview



① Front Camera

② Volume Keys

③ Power Key

④ Menu

⑤ Home

⑥ Back

⑦ Flash and Rear Camera

# SIM Card Installation

A SIM card contains your phone number and other necessary data. Your device has dual SIM slots that both supports 4G(LTE) SIM cards.

## To Install the SIM Card

1. Make sure the device is turned off. Hold the firmly and use eject tool to loosen the SIM card tray.



2. Locate the SIM card slot and insert the proper SIM card into the proper slot. For more information on SIM card installation, check out the included [SIM Card & Micro SD Card Installation Guide](#).

3. To turn on/off a SIM card go to Settings > SIM cards then slide the SIM card sliders. To turn on/off a SIM card's data connection, go to Settings > Data usage, turn on the "Cellular data" option.

## Keys/Touch Points

**Power Key:** To power on/off it, press and hold power key for a few seconds on top of your phone. When it is ON, press the power key once to activate or deactivate the screen.

**Home key:** Touch the key to return to the home screen. In idle screen, touch and hold the key to view recently accessed features.

**Options key:** In standby mode, touch the key to set wallpaper, manage apps, access to system settings. Touch it to view menu options.

**Back key :** Touch to go back to the previous menu.

**Search key :** In standby mode, tap to open search page. In many applications, it activates a search box to search within the application.

New batteries are shipped partially charged. Before using your device,

# Charging battery


New batteries are shipped partially charged. Before using your device, install and charge the battery. Batteries perform best after several full charge / discharge cycles.

## Charging Your battery

Please charge the battery using the following methods:

1. Charge the phone by connecting it to a computer via the USB cable.
2. Connect the USB cable to the phone and the AC adapter. Plug the AC adapter into an electrical outlet to start charging.

As the battery charges, an icon will appear in the status bar of the home screen. When the battery is fully charged, a full battery icon appears on screen.



### Warning:


- Do not remove the battery while the device is charging.
- Use only the AC adapter & USB cable provided with your device.

**Note:** For safety, the battery will stop charging if in danger of overheating.

# Audio Profile/Sleep Mode

## Intelligent keyboard

From the home screen, touch "APP Menu" & select "Settings" , Go to "System profiles" and select the model that you want to. For your Convenience, you may also select Silent Meeting, or Automobile options.



## Sleep Mode

Turn on sleep mode to save your battery power.

- 1.On the home screen, touch "App Menu" & select "Settings"
- 2.Select " Display" .
- 3.Select "Sleep" and choose a time interval from the list.

## Schedule Power On/Off

- 1.On the home screen, touch the "APP Menu" & select "Settings" .
- 2.Select " Scheduled power on & off" .
- 3.Click on the time to change the time and day for the phone to turn on/off automatically.

## Screen Lock

- 1 .On the home screen, touch the "APP Menu" & select "Settings" .
- 2.Select Security then select Screen lock .
- 3.Select the desired type of lock & follow the prompts to set up.

# Phone Features

## Description Icons

Icons	Descriptions	Icons	Descriptions
	Signal searching		Battery charge.
	Signal strength		New message
	You have missed calls		Silent mode
	Data Conn off		Meeting mode
	Wi-Fi network		Airplane mode.
	New Wi-Fi network detected		Bluetooth icon
	USB connected		Alarm set
	USB debugging		Earphone insert.

## Main Menu & Its Functions

Select App Menu to enter the main menu--

Allow you to view a list of features available in your phone.

1、 Browser

By default browser access to the Internet or use Chrome browser.

2、 Calculator

Allows you to make tedious calculations quickly.

3、 Calendar

View the calendar & add events.

4、 Clock

# Phone Features

After entering Clock, touch  to set Alarm; touch  to access to world cities; touch  to access to Timer; touch  to access to Stopwatch.

## 5. Camera

Your product supports for taking photos and video recording. Before taking a photo or video recording, you can set the following options: Flash mode, Store location, Picture size, Picture quality, Countdown timer, Storage Position, Continuous Shot, Face Detection, Select ISO, Exposure, White balance, Timestamp, Focus mode, Anti Banding, Redeye Reduction, Restore to Default Settings, etc. You can press the Thumbnailpicture to view, edit, share the picture or video. Press 'Menu' for more options.

## 6. Contact

To see your list of Contacts. Access phonebook through this function.

## 7. Downloads

In main menu, touch  to enter, you can view the downloaded files or applications.

## 8. FM Radio

In main menu, touch  to enter FM Radio interface, then you can listen to FM radio freely.

## 9. Gallery

Allow you to save & view photos & videos.

## 10. Play Store

Log in to your Gmail account to view all the applications & download from thousands of applications available under the Google Market called Play Store.

Note:

To use this app please connect to an internet connection.

## 11. Messaging

Allow you to view messages sent & received as a thread.




maxwest

# Phone Features

## 12, Music

View the list of songs available in your phone. View the artists, albums, playlists & more.



## 13, Phone

Allow you to make quick outgoing calls.

## 14, File Manager

You could install the files in APK format & also view your files.

## 15, SIM Toolkit

This service is provided by the operator. It provides many types of personalized message services.

## 16, Sound Recorder

Allows you to record sounds.

## 17, Videos

View from list of videos.

# Phone calls/Texting


## To Make Phone Calls

- 1.Touch the phone icon.
- 2.Select SIM1 card or SIM2 card.
- 3.Click on a contact from your contact list to make a call.



## Composing text messages

Gravity 5 LTE automatically corrects and suggests words as you type.



### Cut Copy and Paste.


Touch and hold text content to bring up the magnifying glass, and then slide your finger to move the insertion points. Then choose to cut copy, or paste. It is very easy to copy text from web pages, email, or text messages.

# WLAN

## Turn on WLAN

Gravity 5 LTE supports Wi-Fi which allows you to connect with a Wireless connection. This is useful for surfing internet on phone.

1、 Enter "Settings" interface & Wi-Fi. Trun it on, and select the network you want to connect.



2、 Enter the password, select the connect.

# Connecting to E-mails

## Log into your e-mail accounts.

You may log-in to your e-mail accounts from the phone to access your e-mails.

From the Home screen select "Email" .

Enter your email address, password and tap "Next" .

Select which type of email account you are setting up and complete settings.(POP3 / IMAP / Microsoft Exchange Account)

You will need to enter your user name, password, and server information depending on the type of email account or you can change the settings by tapping "Manual setup" at the top right corner screen. Tap "Next" and select "OK" to accept the activation notification.

## Compose new:

1.Press MENU & select "Compose" .

2.Add recipients by typing a name or email address in the "To" field. Matching contacts will appear. Select a recipient or continue typing in the email address to send to multiple contacts.

3.Once finished typing the mail, select "Send" , "Save as draft" , or "Discard" .

4.The reply tab contains "Reply" , "Reply all" and "Forward" options.



## Delete message:

1.Go to Inbox to display messages.

2.Touch & hold the message you want to delete.

3.Select "Delete" .

# File Transfer

## Connecting Smartphone to PC

Connect the enclosed Micro USB to USB cable to your smart phone and computer.

Once connected successfully, on your phone, slide the top menu down and click on "USB connected" , then, press "Turn on USB storage" button.

A new storage named "Gravity 5 LTE" will appear on your "My Computer" . Click in it to review files in the smart phone and /or to transfer documents between devices. When finished, press" Turn off USB storage" button on phone to disconnect.

Note: Photos taken with the camera will be saved under the a DCIM" folder. Screenshots captured will be saved under "Pictures" folder. Put Music files in the "Music" folder for the files to be played properly.



## Screen Capture

Press Volume(-) and power button at the same time to capture" Screenshot" . All captured screenshot will be saved under gallery.



# Warming

■ Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment .This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and

(2)this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications .However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

■ SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

■ Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body)as required by the FCC.

■ For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that Contains no metal and that positions the handset a minimum of 1.0 cm from the body.

■ Non-compliance with the above restrictions may result in violation of RF exposure guidelines.



maxwest

GRAVITY 5 LTE

User Manual