

# RAZER NABU WATCH



DOWNLOAD  
THE **NABU APP**



CONNECT  
YOUR WATCH



LIVE  
SMARTER

## TABLE OF CONTENTS

1. PACKAGE CONTENTS / SYSTEM REQUIREMENTS .....	3
2. REGISTRATION / TECHNICAL SUPPORT .....	4
3. DEVICE LAYOUT .....	5
4. USING YOUR RAZER NABU WATCH.....	6
5. CONFIGURING YOUR NABU WATCH VIA THE UTILITY APP .....	9
6. SAFETY AND MAINTENANCE.....	19
7. LEGALESE.....	22

## 1. PACKAGE CONTENTS / SYSTEM REQUIREMENTS

### ***PACKAGE CONTENTS***

- Razer Nabu Watch
- Charging cable
- Important product information guide

### ***SYSTEM REQUIREMENTS***

- iPhone 5 / 5S / 5C / 6 / 6 Plus / 6S / 6S Plus with iOS 8 (or higher)
- Android 4.3 (or higher) device with Bluetooth Low Energy (BT 4.0 or higher) capability

---

## 2. REGISTRATION / TECHNICAL SUPPORT

### **REGISTRATION**

Sign up now for a Razer ID account to get real-time information on your product's warranty status. To learn more about Razer ID and all its features, visit [www.razerzone.com/razer-id](http://www.razerzone.com/razer-id). If you are already a Synapse user, register your product by clicking on your email address at the Synapse application and select *Warranty Status* from the dropdown list.

To register your product online, visit [www.razerzone.com/registration](http://www.razerzone.com/registration). Please note that you will not be able to view your warranty status if you register via the website.




### **TECHNICAL SUPPORT**

What you'll get:

- 1 year limited manufacturer's warranty.
- Free online technical support at [www.razersupport.com](http://www.razersupport.com).

### 3. DEVICE LAYOUT




- A. Set
- B. Adjust
- C. Watch Face
- D. Mode
- E. Backlight
- F. Nabu Button

## 4. USING YOUR RAZER NABU WATCH

### **CHARGING THE NABU WATCH**

Connect the charging cable from the Razer Nabu Watch to a PC or a USB charger.



*Reminder: Please remove the Razer Nabu Watch from your wrist before charging it. The approximate time to fully charge the Razer Nabu Watch is 2 hours. Do not leave the Razer Nabu Watch charging overnight.*

### SETTING UP THE RAZER NABU WATCH

Download the Nabu Watch App on iOS or Android and follow the onscreen instructions.



### WATCH MODES

The Nabu Watch contains modes that are represented by different symbols. Listed below are the symbols, their function, and their description. To select a specific mode, press the Mode button and to change the configuration, press the Adjust button.

Symbol	Function	Description
	Second Time Zone	Shows your custom time
	Settings	Use this mode to set the button tone and the Bluetooth on or off.
	Stopwatch	When this mode is selected, the Nabu Watch functions as a stopwatch.
	Alarm	Use this mode if you want the Nabu Watch to alert you at a specific time.
	Timer	When this mode is selected, the Nabu Watch functions as a countdown timer.

### **STATUS INDICATORS**

The Nabu Watch contains indicators that are located on the watch face. Listed below are the indicators, their function, and their description.

Symbol	Function	Description
	Date	Shows the current date (MM – DD or DD-MM)
	Chime	Indicates that the hourly chime is turned on
	Alarm	Indicates that the alarm is currently turned on
	Bluetooth	Shows that the Nabu Watch's Bluetooth is currently turned on
	Day	Shows the current day
	Time	Shows the current time (hour:minute:second)


---

## 5. CONFIGURING YOUR NABU WATCH VIA THE UTILITY APP

*Disclaimer: The features listed here require you to log in to Razer Synapse 2.0. These features are also subject to change based on the current software version and your Operating System.*

### **WELCOME SCREEN**


The welcome screen highlights some of the features you will find on the Razer Nabu app.



Once you are ready to setup your Razer Nabu Watch, tap “*Join Razer*” or “*Sign In*”.


### **JOIN RAZER SCREEN**

To sign up for a Razer ID account, you will need to provide an email, a password, and agree to the Terms of Service and Privacy Policy. Once you have filled out the necessary fields, tap “Next” to continue.



### **PERSONALIZE SCREEN**

The personalize screen allows you to setup your user profile to be used by fitness apps that support the Razer Nabu Watch.




### ***SIGN IN SCREEN***

If you already have a Razer ID account, tap “*SIGN IN*” and input your email and password.



### **DASHBOARD SCREEN**

The Dashboard screen allows you to pair a Razer Nabu Watch to your account as well as configure settings related to your Razer Nabu Watch.



## Pairing

To pair a Razer Nabu Watch to your account, tap the  icon on the dashboard screen. The pairing screen will guide you in pairing the Razer Nabu Watch with your smartphone. Simply follow the onscreen instructions until the app successfully finds your Razer Nabu Watch.



When the app has successfully found your Razer Nabu Watch, a 4-digit code will be shown on the smartwatch. Type this code on the app to authenticate your Razer Nabu Watch.




Once you have successfully paired the Razer Nabu Watch to your account, a short tutorial will introduce you to some of the feature of your smartwatch. Once you are finished, tap “Done”.



## Settings

On the Dashboard screen, you may tap the image of the Razer Nabu Watch to access numerous settings such as notifications, display, and alarms.




Listed below are the settings and their corresponding functions:

- |                       |   |
|-----------------------|---|
| Details               | - View your Razer Nabu Watch's information, update your smartwatch's firmware, or un-associate your smartwatch from your phone. |
| Notification Settings | - Choose which instances you would like to be notified.   |
| Activities            | - Select which goals are displayed on the Nabu screen.  |
| Display Settings      | - Customize your Razer Nabu Watch's screen style and more.  |
| Watch Settings        | - Allows you to sync or manually set the time, set a world time, and enable or disable chime.                                   |
| Alarms                | - Create silent alarms for discreet announcements.  |
| Social settings       | - Enable or disable Handshake and Pulse functionalities   |
| Connected Apps        | - Enable or disable 3 <sup>rd</sup> party apps such as Facebook and Twitter.  |
| Sleep Tracking        | - Enable or disable tracking of your sleep pattern  |

## ***DRAWER MENU***

The drawer menu offers a wide variety of information regarding you, your Razer Nabu Watch, and the App.



Listed below are the menu options and their corresponding functions:

- Dashboard - This is your default screen where you can view your progress and access your smartwatch's settings.
- Goals - This allows you to customize your fitness goal settings.
- Devices - View details regarding all Razer devices that are associated to your app.
- Help - Access the FAQ database and digital watch guide to help you better understand your Razer Nabu Watch.
- About - View the app's version as well as legal documentations.
- Sign Out - This allows you to log out your account from the app.

## 6. SAFETY AND MAINTENANCE

### **SAFETY GUIDELINES**

In order to achieve maximum safety while using your Razer Nabu Watch, we suggest that you adopt the following guidelines:

1. Should you have trouble operating the device properly, unplug and/or remove the device and contact the Razer hotline; or go to [www.razersupport.com](http://www.razersupport.com) for assistance. Do not attempt to fix the device yourself.
2. Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.
3. Charge the Razer Nabu Watch in accordance with the recommended charging time and do not leave the battery charging overnight. Do not wear the Razer Nabu Watch while it is charging.
4. Do not expose the Razer Nabu Watch to liquids while charging. Exposing the Razer Nabu Watch to these conditions may result in an electric shock.
5. Do not tamper or abuse the Razer Nabu Watch; including but not limited to dropping, crushing, excessive bending, puncturing, shredding, microwaving, incinerating, or inserting foreign objects into the Razer Nabu Watch.
6. Do not use abrasive cleaners and/or harsh cleaning agents to clean the Razer Nabu Watch.
7. Do not expose the Razer Nabu Watch to extremely high or low temperatures such as leaving the Razer Nabu Watch in direct sunlight or in snowy weather for extended periods of time.
8. Do not expose the Razer Nabu Watch to open flames such as stoves, candles, or fireplaces.
9. Do not expose the inner band to organic solvents such as alcohol, acetone, and detergent.
10. Dispose the product in accordance with your local environmental laws and guidelines.

Prolonged contact may contribute to skin irritation or allergies in some users. If you notice any signs of skin redness, swelling, itchiness or other skin irritation, please discontinue use or wear the product clipped over a piece of clothing. Continued use, even after symptoms subside, may result in renewed or increased irritation. If symptoms persist, consult your doctor. Please follow these care and wearing tips:

1. Clean and dry your Razer product regularly, particularly in areas in contact with the skin. Use a clean, damp cloth. Do not wash product under a faucet.

2. Wear your Razer product loosely enough to allow air circulation. Review the sizing guide.
3. Use skin care products sparingly on the areas of the skin covered by your Razer product.
4. Take the product off from time to time to clean it and allow for your skin to be uncovered.

#### ***LITHIUM-ION POLYMER RECHARGEABLE BATTERY***

The Razer Nabu Watch contains an internal, lithium-ion polymer rechargeable battery. In general, the life expectancy of this battery depends upon use. Prolonged charging may decrease battery life over time. If the battery does not charge after several attempts, it may be non-operational and you may need to contact customer support. Do not attempt to replace the Razer Nabu Watch's lithium-ion polymer rechargeable battery yourself.

#### ***NON-RECHARGEABLE COIN CELL BATTERY***

The Razer Nabu Watch contains an internal, non-rechargeable coin cell battery (CR2032). In general, the life expectancy of this battery is 12-18 months. Low battery power is shown on the watchface display. This is indicated by dimly lit symbols and indicators, or when the display goes blank. Continuous use of the Nabu Watch while the coin cell battery power is low may result in malfunction. Replace the battery as soon as possible. Do not attempt to replace the Razer Nabu Watch's coin cell battery yourself; instead, seek the assistance of your original retailer or authorized "Razer" service center. Note that you will be charged for replacement of this battery, even if replacement is required within the watch's warranty period.

#### ***TRACKING***

The accuracy of our sensors and associated calculations (i.e. distance traveled and calories burned) will vary with use.

***IMPORTANT NOTICE FOR USE IN HEALTHCARE ENVIRONMENTS***

This Razer device is not intended for scientific or medical use but is designed to provide meaningful data to help users reach their health and fitness goals. This Razer device is not a medical device and is not listed under UL or IEC 60601 (or equivalent). This device should be kept at a certain distance to avoid harmful effects to patients or medical equipment.

***AVIATION USAGE RESTRICTIONS***

Certain restrictions apply to this device while on-board an aircraft. Razer encourages you to understand these restrictions to ensure the flight's safety and security. Contact your airline to determine if Personal Electronic Devices (PEDs) can be used during the flight. Your Razer device utilizes Bluetooth Low Energy, which is considered safe by most airlines

## 7. LEGALESE

### ***COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION***

© 2016 Razer Inc. All rights reserved. Razer, For Gamers By Gamers, and the triple-headed snake logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks are the property of their respective owners. Actual product may differ from pictures. Information is correct at time of printing.

iOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. Apple, the Apple logo, and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android and Google Play are trademarks of Google Inc.

Microsoft, Windows, Windows Phone and Windows logo are trademarks of the Microsoft group of companies.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Razer is under license.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer Nabu Watch (the “Product”) may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

### ***LIMITED PRODUCT WARRANTY***

For the latest and current terms of the Limited Product Warranty, please visit [www.razerzone.com/warranty](http://www.razerzone.com/warranty).

***LIMITATION OF LIABILITY***

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

***COSTS OF PROCUREMENT***

For the avoidance of doubt, in no event will Razer be liable for any costs of procurement unless it has been advised of the possibility of such damages, and in no case shall Razer be liable for any costs of procurement liability exceeding the retail purchase price of the Product.

***GENERAL***

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.