



moto 360

- At a glance
- Start
- Android Wear
- Motorola Connect
- Features
- Watch bands
- Want more?
- Troubleshooting
- Safety
- Search






At a glance

At a glance First look Quick start

First look

Your new Moto 360 (2nd Gen.) watch keeps you up to date without taking you out of the moment. Glance at your wrist to see updates. Say “OK Google” to ask a question or start a voice command. At night, place your watch on the charging dock that doubles as a desk clock.



Note: your watch may look different than the images shown in this guide.

SAR This product meets the applicable national or international RF exposure guidance (SAR guideline) when used normally as worn on the body. The SAR guideline includes a considerable safety margin designed to ensure the safety of all persons, regardless of age and health.

Quick start

When you're up and running, make sure you explore what your watch can do.

- **One watch, many faces:** change the entire look of your watch with a few screen touches. See “**Change watch faces**”.
- **Notifications:** see information you need to know, when you need it. See “**Notifications**”.
- **Directions on your wrist:** let your watch guide you safely and discreetly to your destination. See “**Navigation**”.
- **Voice commands:** just tell your watch what you need. You may be surprised by how many things Google™ can do to help you manage your busy day. See “**Voice commands**”.
- **Stay fit:** check your activity and heart rate. See “**Moto Body**”.

Water resistance note: this device is IP67 dust and water resistant—not waterproof. Not for use while swimming, diving or engaging in other underwater activities. Avoid prolonged exposure to water, and/or exposure of leather band to water.



Menu

More



Back

Next



<https://www.mobile-manuals.com/>



Start

Start
Charge up
Download & pair
Power on & off
Tips and tricks



Menu



Back



More




Next


Charge up

Before using your Moto 360 (2nd Gen.) for the first time, remove the plastic film from the back of the watch and **charge it for two hours** or until the charge level indicator on the watch screen shows 100%.

- 1 Insert the micro USB connector cable in the charging dock and plug the cable into a power outlet. Your watch works best with the Motorola Wireless Charging Dock (2nd Gen.). Always use the cable and wall charger that came with your watch.




- 2 Place your watch on the charging dock.



- 3 Use the charge level indicator to determine when your watch is fully charged.

Swipe down on the watch face to change the charging display screen colour.





Start


Start
Charge up
Download & pair
Power on & off
Tips and tricks



Download & pair*

Pairing your watch with your phone is quick and easy.


- 1 If you have an Android phone, download the Android Wear app from Google Play™ (tap Apps (☰) → **Play Store**). If you have an Apple iPhone device, download the Android Wear app from the Apple App Store.
- 2 Open the Android Wear app on your phone and follow the prompts to pair your phone and watch over a Bluetooth® connection.



* Requires a phone running Android 4.3+ or iOS 8.2+.

<https://www.mobile-manuals.com/>

- 3 You can also stay connected over Wi-Fi** when you leave your phone in another room or at work. To turn Wi-Fi on or off, swipe left on the watch face, then scroll down to **Settings** → **Wi-Fi settings**.



** Does not support Wi-Fi networks that require access through a captive portal. Not available for Apple iPhone.



Start

Start
Charge up
Download & pair
Power on & off
Tips and tricks



Menu

More



Back

Next



- 4 Turn on watch notifications so your phone can send updates to your watch. You can turn Android Wear notifications on or off at any time on the phone's **Settings** menu.

Tip: to learn more about the Android Wear app, see "**Android Wear**".

Power on & off



To turn on, press and hold the power button until your watch vibrates.

To **turn off**, swipe left on the watch face, then scroll down and tap **Settings** → **Power off**.

Caution: before using your device, please read the safety, regulatory and legal information at www.motorola.com/moto360legal

<https://www.mobile-manuals.com/>



Start

Start
Charge up
Download & pair
Power on & off
Tips and tricks



Menu

More



Back



Next







Tips and tricks

- **Trusted device:** when you pair your watch with your phone for the first time, the phone may ask if you want to set your watch as a trusted device. If you agree, your phone will remain unlocked when the watch is within range and connected with the phone.

Note: to use this feature, you need to set a screen lock on your phone and set your watch as a trusted device. Corporate security policies installed on your phone may prevent you from using this feature.

Tip: to manually set your watch as a trusted device, on your phone tap Apps  →  **Settings** → **Security** → **Smart Lock** → **Trusted Devices**.

- **Quickly dim the watch screen:** press the power button or press your palm onto the screen until it vibrates. To turn on the screen, press the power button or tap the screen.
- **Battery charge level:** to see the battery charge level, drag down from the top to the middle of the watch screen.
- **Status indicators:** status indicators on the watch screen show when watch notifications are turned off , when the connection to your phone is lost , or when the watch is in airplane mode .

- **Voice commands:** say “OK Google” to start using voice commands. You’ll see a white screen with a red  icon. Say a voice command.

Tip: on the voice command screen, you can scroll down to see a list of suggested voice commands, which you can also tap to activate.

- **Adjust notifications:** to adjust notification settings, swipe down from the top of the watch face. From there, swipe left to activate **Theatre mode** (screen and notifications off). Keep swiping left to boost screen brightness or open the **Settings** menu.

- **Screen brightness:** to change the screen brightness, swipe left on the watch face, then scroll down and tap **Settings** → **Adjust brightness**.

- **Text size:** to increase or decrease the size of the text you see on your watch, swipe left on the watch face, then scroll down and tap **Settings** → **Font size**.

- **Hands-free scrolling:** to turn on/off hands-free scrolling for watch notifications, swipe left on the watch face, then scroll down and tap **Settings** → **Wrist gestures**. (For more, see “**Hands-free scrolling**”.)

- **Wi-Fi:** to turn on/off Wi-Fi on your watch, swipe left on the watch face, then scroll down and tap **Settings** → **Wi-Fi settings**. (For more, see “**Download & pair**”.)



Start

Start
Charge up
Download & pair
Power on & off
Tips and tricks



Menu



Back

Next



- **Bluetooth devices:** to link your watch with another Bluetooth device, swipe left on the watch face, then scroll down and tap **Settings** → **Bluetooth devices**.
- **Always-on screen:** this feature keeps the watch screen dimly illuminated when not in use. It also keeps always-on apps (like maps and fitness) running in ambient mode to optimise battery life. To turn on, swipe left on the watch face, then scroll down and tap **Settings** → **Always-on screen**.
- **Note:** to conserve battery life between charges, switch off this feature when you don't need it.
- **Aeroplane mode:** swipe left on the watch face, then scroll down and tap **Settings** → **Aeroplane mode**.
- **Accessibility:** to adjust accessibility settings on your watch, swipe left on the watch face, then scroll down and tap **Settings** → **Accessibility**.
- **Restart:** swipe left on the watch face, then scroll down and tap **Settings** → **Restart**.
- **Factory reset:** swipe left on the watch face, then scroll down and tap **Settings** → **Factory reset**.

Use this feature to clear all settings and information about the current paired phone, so you can pair your watch with a different phone.

Warning: when you reset your watch to its factory settings, all your user data and downloaded apps stored on the watch will be deleted. Resetting your watch will *not* factory reset your phone or tablet.

- **Screen lock:** set your watch to automatically lock the screen when you remove the watch. Swipe left on the watch face, then scroll down and tap **Settings** → **Screen lock**. Follow the instructions to draw a pattern you'll use to unlock the screen.
- **Watch info:** to see information about your watch (software version, connection status, system updates, legal notices and more), swipe left on the watch face, then scroll down and tap **Settings** → **About**.



Android Wear

Android Wear

Quick start: Android Wear

Adjust general settings


Adjust device settings

Assign apps to voice actions


Quick start: Android Wear

After you've paired your phone and watch (see "**Download & pair**"), use the Android Wear app on your phone to adjust general watch settings.

Tap Apps  →  **Android Wear** to open the app.



Adjust general settings

Tap  on the Android Wear screen to adjust general settings.

- **Calendar settings:** show or hide notifications from your phone's Calendar app and/or the Calendar associated with your Google™ account.
- **Block app notifications:** stop specific apps from sending notifications to your watch.
- **Mute phone alerts & calls:** mute calls and notification alerts on your phone when it's connected to your watch. (Your watch may vibrate for notifications, based on the app settings on your phone.)
- **Cloud sync:** when you turn on cloud sync, your watch will use a Wi-Fi connection to stay in sync when you are out of Bluetooth® range of your phone.
- **Together:** pair your watch face with a friend's watch face to share photos and emojis and to share your activities (like if you're working out, on the phone or stuck in traffic).



Menu

More



Back

Next





Android Wear

Android Wear

Quick start: Android Wear

Adjust general settings

Adjust device settings

Assign apps to voice actions

Adjust device settings

Tap  at the top of the Android Wear screen, then tap **Moto 360** to adjust Moto 360 device settings.

- **Connected:** tap the switch to disconnect your Moto 360 watch from your phone. Tap the switch again to reconnect the watch and phone.
- **Always-on screen:** you can keep the watch screen dimly illuminated when not in use. To turn on, tap the switch.
Tip: to conserve battery life between charges, turn this setting off when you don't need it.
- **Tilt to wake screen:** show the watch screen when you tilt your wrist to look at the watch.
- **Card previews:** preview some sample notification cards on your watch.
- **Actions:** you can use Google apps or other apps to perform specific voice actions on your watch. Select an action in the list, then select the app you want to use to perform the action.
- **Watch battery:** see your watch's current battery charge.
- **Watch storage:** see how much memory storage space is available on your watch and how much memory is being used by your watch apps.
- **Re-sync apps:** sync all of the apps on your watch.

- **Forget watch:** delete all information about your Moto 360 watch from the Android Wear app.

Tip: this feature is handy when you want to use a different watch with your phone.

Assign apps to voice actions

You can use Google apps or other apps to perform specific voice actions on your watch.

Scroll down on the Android Wear screen to the section named **Jump into action with watch apps**. Select an action in the list, then select the app you want to use to perform the action.



Menu

More



Back

Next



<https://www.mobile-manuals.com/>



Motorola Connect


Motorola Connect
Quick start: Motorola Connect
Customise watch faces
More watch options

Quick start: Motorola Connect*


Use the Motorola Connect app on your phone to set up and manage your Moto 360 watch and other Motorola smart devices.

Tip: if you don't have the Motorola Connect app on your Android phone, get it on Google Play (tap Apps ☰) → **Play Store**).

Tap Apps ☰ → **Connect** to open the app.



Then tap the Moto 360 illustration to manage your watch.



Menu

More



Back

Next



* Not available for Apple iPhone.

<https://www.mobile-manuals.com/>




Motorola Connect
Quick start: Motorola Connect
Customise watch faces
More watch options

Customise watch faces

Use Connect to customise watch faces that have the **Moto** logo on them. You can change background colours, accent colours and more.

- 1 Tap Apps (☰) → **Connect**, tap the Moto 360 illustration, then tap **Watch faces**.
- 2 Swipe left or right on the watch faces to select the one you want, then tap **CUSTOMISE**.
- 3 Changes settings, then tap **APPLY**.

Design your own watch face: Select the **My Design** watch face and tap **CUSTOMISE**. Choose whether you want to create an analogue or digital watch face, select design elements and colours, then insert a background image or your own photo. When you've finished, tap  to share your design with your friends.

More watch options

Dock Mode

Tap Apps (☰) → **Connect**, tap the Moto 360 illustration, then scroll down and tap **Dock Mode** to pick from five colours for the watch charging display.

Locate your watch

Tap Apps (☰) → **Connect**, tap the Moto 360 illustration, then scroll down to **Location** to view the last known location of your watch.

Help

Tap Apps (☰) → **Connect**, tap the Moto 360 illustration, then scroll down and tap **Need help?** To learn more about your watch and the Motorola Connect app.

Related apps

Tap Apps (☰) → **Connect**, tap the Moto 360 illustration, then scroll down to **Related apps** to open Android Wear or Moto Body. Or, tap **Browse apps in Play Store** to find new apps for your watch.



Menu

More



Back

Next





Features

Features

Change watch faces

Notifications

Swipe from apps, to contacts, to take actions


Voice commands

Navigation

Moto Body

Change watch faces


Define your style.

- 1 Touch and hold the screen to see all your watch faces.
- 2 Swipe left or right to find the watch face you want.
- 3 Tap  to customise the new watch face or just tap the new watch face to select it.



Tip: you can customise watch faces, even design your own watch face with the Motorola Connect app. For more info, see "**Motorola Connect**".

Live dials

Some watch faces feature Live Dials, which provide important info like weather and your daily steps at a glance. To customise the Live Dials, tap  when you select the watch face.



You can also customise Live Dials with your favourite apps*, like MyFord Mobile and Shazam. (The app needs to be installed on your phone). Tap the Live Dial to launch the app.

Notifications

Notifications give you the information you need, when you need it. A slight vibration notifies you of incoming calls, messages and more. A quick glance shows who's trying to get in touch with you.

You can perform actions on some notifications. Swipe left on a notification to see if any actions are available.


1



Drag up to view a notification card.

2

Swipe up to see more notifications.



Swipe left for more details and options.

Swipe right to dismiss the notification from your watch and phone.

Swipe down to minimise the notification and return to the home screen.



Menu

More



Back

Next



* Not available for Apple iPhone.

<https://www.mobile-manuals.com/>



Features

Features

Change watch faces

Notifications

Swipe from apps, to contacts, to take actions

Voice commands

Navigation

Moto Body

Hands-free scrolling

Flip through watch notifications with a flick of your wrist. To activate/deactivate wrist gestures, swipe left on the watch face, then scroll down and tap **Settings** → **Wrist Gestures**.

To see the next notification: twist your wrist quickly forwards, then slowly back towards you.



Fast

To return to the previous notification: twist your wrist slowly forwards, then quickly back towards you.



Fast

Manage watch notifications

Most notifications on your phone also appear on your watch. You can manage the notifications that show on your watch.

- **Block notifications from a specific app:** open a notification card on your watch, then swipe left on the notification until you see **Block app** (⊘). Tap **Block app**, then tap the tick to confirm.

To **unblock** notifications from the app, launch Android Wear on your phone, tap **Settings** → **Block app notifications**, then tap **X** by the app name to unblock it.

Tip: if you don't want to see Google Now cards, turn off Google Now on your phone.

- **Select notification types (phones running Android 5.0):** to change the types of notifications that show on your watch, swipe down from the top of the watch screen. Tap an icon on the screen to select **None**, **Priority** or **All**, then swipe up from the bottom of the screen. An icon appears on the screen when you select none (⊘) or priority (★) notifications.
- **Mute your watch (phones running Android 4.3 and 4.4):** to prevent new notifications from lighting the screen or vibrating your watch, swipe down from the top of the watch screen to see the **Mute** option. Tap the screen to turn mute **On** or **Off**, then swipe up from the bottom of the screen. The mute icon (⊘) appears on the screen when mute is turned on.



Menu

More



Back

Next





Features

Features

Change watch faces

Notifications

Swipe from apps, to contacts, to take actions

Voice commands

Navigation

Moto Body



Menu

More



Back

Next



- **Turn off notifications temporarily (theatre mode):** to **turn off** your watch's screen so the display doesn't light up and notifications don't appear, press the power button twice quickly. to **turn on** your screen again (and turn off theatre mode), press the power button twice quickly.

While your watch is in theatre mode, you can temporarily turn on the screen by pressing the power button.

Tip: to turn on/off theatre mode from the watch menu, swipe down from the top of the watch screen, then swipe left from the right side of the screen until you see **Theatre mode**. Tap the screen to select **On** or **Off**.


Swipe from apps, to contacts, to take actions

Swipe left from the right side of the screen to access your apps. Recently used apps appear at the top of the list.

Swipe left again to see a list of your contacts. Tap a contact to quickly call, text or email.

Swipe left again to execute voice commands. Scroll down to see a list of voice actions you can perform.

Voice commands

Say "OK Google" to start using voice commands. You'll see a white screen with a red  icon.

Tip: on the voice command screen, you can scroll down to see a list of suggested voice commands, which you can also tap to activate.

Try a few commands like these:

- "Remind me to buy flowers for Ana."
- "What is my agenda for today?"
- "How tall is the Eiffel Tower?"
- "Will it rain today?"
- "Wake me up in 30 minutes."
- "Show me my steps."

Navigation*

Turn-by-turn navigation instructions on your wrist—what could be easier?

Tell your watch where you want to go. Then follow the step-by-step navigation instructions on your watch screen.

Tip: navigation instructions that you set up on your phone will also appear on your watch screen.



Features

Features

Change watch faces

Notifications

Swipe from apps, to contacts, to take actions

Voice commands

Navigation

Moto Body



Menu

More



Back

Next





Moto Body

The Moto Body app on your watch helps you track your fitness and activity levels and offers coaching advice to help you meet your goals and maintain a healthier lifestyle.


You can track your steps, calories burned, heart activity and heart rate. Your data won't be shared with any third parties without your consent.

See your steps

A notification card on your watch shows how many steps you've taken each day. To dismiss the card, swipe it right on your watch screen.


Select the Moto Body app to count your steps: on your phone, tap Apps  →  **Android Wear**, then scroll down to **Jump into action with watch apps** and tap **More actions** → **Show me my steps** → **Moto Body steps**.

Speak to see your steps: say "OK Google" to activate voice commands, then say "Show me my steps". Your watch shows the estimated number of steps you've taken today.

Use the menu to see your steps: swipe left on the watch face, then scroll down and tap **Moto Body**. Scroll down on the Moto Body app screen and tap  **Steps**.


See calories burnt

A notification card shows how many calories you've burnt each day, and how far you are from reaching your goal. To dismiss the card, swipe it right on your watch screen.



Use the menu to see the calories you've burned: swipe left on the watch face, then scroll down and tap **Moto Body**. Scroll down on the Moto Body app screen and tap  **Calories**.

See your heart activity

Moto Body encourages you to get at least 30 minutes of activity a day, five times a week. A notification card shows your heart activity, and how far you are from reaching your goal. To dismiss the card, swipe it right on your watch screen.


Use the menu to see your heart activity: swipe left on the watch face, then scroll down and tap **Moto Body**. Scroll down on the Moto Body app screen and tap  **Heart min**.

Check your heart rate

Select the Moto Body app to see your heart rate: on your phone, tap Apps  →  **Android Wear**, then scroll down to **Jump into action with watch apps** and tap **More actions** → **Show me my heart rate** → **Moto Body heart rate**.

Tip: make sure your watch fits snugly on your wrist to get an accurate heart rate measurement.

Speak to see your heart rate: say "OK, Google" to activate voice commands, then say "Show me my heart rate". Your watch shows your current heart rate.

Use the menu to see your heart rate: swipe left on the watch face, then scroll down and tap **Moto Body**. Scroll down on the Moto Body app screen and tap  **Heart rate**.



Features

Features

Change watch faces

Notifications

Swipe from apps, to contacts, to take actions

Voice commands



Navigation

Moto Body




Turn off Moto Body notifications on your watch

To prevent Moto Body cards from automatically appearing on your watch throughout the day, swipe left on the watch face, then scroll down and tap **Moto Body** to open the app. Swipe left to open the settings screen, then scroll down and tap **Moto Body: Notifications enabled** to turn it off.


Moto Body phone app*

For a richer experience, get the Moto Body phone app for your Android phone on Google Play (tap Apps  →  **Play Store**).

The app's intuitive dashboards and charts help you visualise and track your activities on a daily, weekly and monthly basis. You can also choose to receive a weekly email summary of your activities and trends, with personalised insights and suggestions. And the Moto Body phone app lets you securely save your wellness data to the cloud to back it up.

To set up your user profile on the Moto Body phone app, tap Apps  →  **Moto Body** →  → **Settings**.

Enter your personal details (height, weight, birthdate, gender). When you've finished, tap **Done**. Your user profile information is listed on the Settings page.



Select or set up your Motorola ID.

Select US or metric measurements.

Tap a field to enter your information.

Scroll down to adjust settings.

Motorola will use your personal demographic information to provide you with more accurate wellness tracking and will not share your profile information without your consent.



Menu

More



Back

Next



* Not available for Apple iPhone.

<https://www.mobile-manuals.com/>



Watch bands

Watch bands

Remove/replace your watch band


Watch band warning

Care for the leather watch band

Remove/replace your watch band

Quick-release bands for your Moto 360 (2nd Gen.) watch are designed to be swapped easily.

To remove the watch band: place your Moto 360 face down on a soft cloth. Slide the metal latch on one band towards the centre of the band to release its pin from the watch. Then gently angle the band away from the watch to remove it. Repeat with the other band.



To attach the watch band: take one band and insert the pin on the side opposite the latch into the hole in the watch. Slide the latch towards the centre of the band and insert its pin into the other hole. Tug gently to ensure the band is secure. Repeat with the other band.

Tip: for leather watch bands, make sure the band with the buckle is on the top side of the watch.

Watch band warning

Your Moto 360 watch uses custom designed watch bands. Using standard off-the-shelf watch bands, especially metal bands, may cause significant damage to your watch. Damage caused by using a non-Motorola watch band, or by its improper replacement, is not covered by the warranty.

Care for the leather watch band

If your watch has a leather watch band, please note that the leather watch band has been hand treated with several stain coats to give a rich finish. Some wear and transfer of colour may be possible. As with many leathers, please use discretion when wearing lighter coloured garments.

To clean, wipe with a soft, damp cloth. Do not use any polishes or creams. Like most leather products, the watch band must be treated with care. Direct exposure to water is not recommended.

Resize your metal watch band

Do you need to resize your metal band? We recommend taking your Moto 360 to a jeweller or watch repair shop for assistance.

Want a new band?

Order new watch bands at www.motorola.com/mymoto360.



Menu

More



Back

Next





Want more?

Want more?
Get help



Menu



Back

More








Next



Get help

There's more help, updates and information right here:

- **Help:** for more info and help with your watch: on your phone, tap Apps  →  **Android Wear** → Menu  → **Help & Feedback**.
- **Tutorials and updates:** get walk-through tutorials, help, guides, software updates and more at www.motorola.com/mymoto360.
- **Join the conversation:** talk, learn and share with other Moto 360 users in our  Google+™ community at moto360community.com.
- **News:** get the latest news, apps, tips and tricks, videos and so much more—join us on:

 YouTube™ www.youtube.com/motorola

 Facebook® www.facebook.com/motorola

 Twitter www.twitter.com/motorola

<https://www.mobile-manuals.com/>



Troubleshooting

Troubleshooting
Unresponsive watch
Factory reset
Updates



Menu



Back

More



Next



Unresponsive watch

In the unlikely event that your watch becomes unresponsive, press and hold the power button for 25 seconds to force a power down. Then switch the watch back on as usual (see “**Power on & off**”).

Factory reset

Swipe left on the watch face, then scroll down and tap **Settings** → **Factory reset**.

Use this feature to clear all settings and information about the current paired phone, so you can pair your watch with a different phone.

Warning: when you reset your watch to its factory settings, all your user data and downloaded apps stored on the watch will be deleted. Resetting your watch will *not* factory reset your phone or tablet.

Updates

When a software update for your watch is available, your watch will notify you that an update is ready to install. Follow the instructions to update your watch software.

<https://www.mobile-manuals.com/>



Copyright & trademarks

Motorola Mobility LLC
222 W. Merchandise Mart Plaza
16th Floor
Chicago, IL 60654
USA

www.motorola.com

Certain features, services and applications are network-dependent and may not be available in all areas; additional terms, conditions and/or charges may apply. Contact your service provider for details.

All features, functionality and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

Note: the images in this guide are examples only.

MOTOROLA and the Stylised M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. Android, Google and other trademarks are owned by Google Inc. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution Licence. All other product or service names are the property of their respective owners.

© 2015 Motorola Mobility LLC. All rights reserved.

Caution: Motorola does not take responsibility for changes/modification to the transceiver.

Product ID: Moto 360 (2nd Gen.)

Manual number: 68017961003-A



Menu

More



Back

Next

